

Rug Doctor Support: 1-800-784-3628 | www.rugdoctor.com

Machine/Tool ID:	DAGL-1 Appliance Dolly w/Manual Belt Tightener
Vendor:	Gleason Industrial Products / Gleason Group
Vendor Website:	www.milwaukeehandtrucks.com
Mfg. Support Phone No.:	414-529-8357

Tool Application: Securely and safely move large appliances, water heaters, furniture, and similar items with ease. Up to 800 lbs. capacity.

Operation Guide: Read all instructions completely before you begin.

USER MUST CAREFULLY READ AND FULLY UNDERSTAND ALL INSTRUCTIONS BEFORE USING THIS DOLLY. Before

operating the dolly, renter agrees to fully read, understand, and follow all safety warnings and instructions set forth below, which can be found on Rug Doctor's website (www.rugdoctor.com).

USING THE DOLLY

-		
1	Make sure there is a clear, obstacle-free path between the heavy items you are moving with the appliance dolly and the final point/destination.	
2	Get a helper as loading and using an appliance dolly is not a job for a single person. Have a helper by your side. A person you can trust and rely on when things get difficult.	
3	Move the dolly up to the edge of the appliance, push/lift the appliance up and slide the dolly's lift plate underneath it. Best practice is to load your appliances from the side, not the back. The sides typically have a smooth even surface that will sit flat against the dolly's padded rails allowing you to strap it more securely and helps prevent damaging any of the mechanical components that are often positioned on the back of appliances. Refer to your appliance's owner's manual for additional moving instructions/warnings and moving preferences.	
4	IMPORTANT! Secure with tape, electrical cord(s) to the back of the appliance to avoid accidents during the haul.	
5	Secure the appliance onto the appliance dolly using the belt straps. Aim or place the straps roughly to the central part of the appliance, then tighten them around the load.	
6	To tighten the belt, insert long end of belt and pull through sliding roller buckle. Pull until belt is tight. Tie half hitch knot with loose end of belt. See Eccentric Crank Lock Instructions label on Appliance Dolly for additional information.	
7	To Lock Load: Turn belt tightener handle in opposite direction to lock the load. This adds the final amount of tension to the belt to keep it secure. CAUTION! Keep hands away from stopping location of handle.	
8	Stand behind the dolly and put one foot on the wheel axle. Step back a foot or two with your other foot. Have your helper push back on opposite side of the appliance while you pull back on the dolly handle to cradle the weight of the appliance on the lift plate of the dolly. Tilt back the appliance dolly until the load is balanced onto the dolly's wheels.	
9	Travel backward with the dolly to go up stairs or ramps. Have your helper push and lift while you pull and steer the wheels of the dolly in the right direction.	
10	Move the appliance to where you want it and then slowly tilt the dolly forward until the appliance rests squarely on the floor. Undo the strap. Tilt the appliance up to remove its weight from the lift plate and slide the dolly out from beneath it. Rewrap the strap around the dolly.	



Safety Guide: Read all instructions completely before you begin.

USER MUST CAREFULLY READ AND FULLY UNDERSTAND ALL INSTRUCTIONS BEFORE USING THIS DOLLY. When using the dolly, basic precautions should always be followed, including the following:

WARNING! Wheels may scratch, dent, or damage certain types of flooring. Cover your floor surface prior to transporting products with any moving equipment.

- WARNING! THIS HAND TRUCK/DOLLY IS NOT TO BE USED FOR LIFTING OR TRANSPORTING PEOPLE, ANIMALS, OR HAZARDOUS MATERIALS.
- CAUTION: Observe safety measures when handling heavy objects.
- Inspect appliance dolly before use. **DO NOT** use a damaged appliance dolly. If dolly is damaged or broken, immediately return to rental location and notify Rug Doctor at (800) 784-3628. Do not attempt to repair a damaged or broken dolly under any circumstances.
- CAUTION: Do not move large appliances by yourself. Don't overexert yourself. A short lift onto a truck can strain your back. Have more than one person help move appliances down stairwells to keep the dolly from getting away from you.
- Heavy appliances can cause injury or damage if mishandled on the dolly. It is always best to push loads rather than pulling them, keeping knees slightly bent and your back straight, so your legs, not your back, do the work.
- While loading the dolly, use your knees rather than your back or arms to lift.
- Make sure your loads are low enough to see over. We recommend a maximum height of not more than 5 ft.
- Always check your weather conditions. Do not use on wet or slippery surfaces.
- Wear sturdy shoes with nonskid soles. ANSI-approved steel-toed shoes are recommended to protect your feet from dropped loads.
- Wear gloves that give you a good grip.
- Avoid loose or baggy clothing that could trip you or get caught in the dolly wheels.
- Place heavy objects at the bottom.
- Make sure the load is stable and won't fall or shift.
- Stop at corners and doorways and always look before pushing forward.
- Avoid walking backwards, unless you need to maneuver in a tight space.
- Never try to lift more than you can manage safely. If you have any back or knee issues, please consult with your physician prior to using.
- Keep children and others at least 25 feet away during loading and unloading.
- This product is not intended for use by persons under the age of 18.
- Do not use for objects over 800 pounds.
- Do not move anything without first securing the strap around the appliance.
- Make sure there is a clear, obstacle-free path between the heavy items you are moving with the appliance dolly and the final point/destination.
- Always maintain a safe speed and keep the dolly under control.
- Do not leave dolly unattended when loaded.
- Always park the dolly in a safe area, never in aisles or other places where they may cause a trip hazard or traffic obstruction.
- **WARNING!** Injury can occur by getting your hand pinched between the handles and a nearby stationary object, so take care when working your way through tight spaces. The use of gloves can provide extra protection.



WARNING This product can expose you to chemicals including Di(2-ethylhexyl)phthalate (DEHP), which is known to the State of California to cause birth defects or other reproductive harm, and lead, which is known to the State of California to cause cancer, birth defects, and other reproductive harm. For more information, go to www.P65Warnings.ca.gov.