



Tile & Grout Cleaner

Operational Guide and Customer Safety

RugDoctor®

1-800-784-3628



QUICK START

- 1 **If** your steamer has a pressure release valve, close before starting. **Not all steamers have a release valve.**
- 2 Remove cap and add tap water.
➤ **DO NOT ADD CHEMICALS TO WATER.**
- 3 Connect hose and cleaning attachment.
➤ You will hear a click when connected.
- 4 Plug into electrical outlet.
➤ The steam cleaner should be the only appliance plugged into an outlet.
➤ *Use only a 12-gauge extension cord with maximum length of 25ft.*
- 5 Press the POWER and STEAM buttons.
➤ *It will take 10 minutes before your steamer is ready to use.*
➤ The steamer is ready when the pressure dial reads greater than 4.
- 6 Steam control dial. Increases and decreases the amount of steam released. Use on medium or low setting.



LOW WATER ALERT

During start-up or use, the steamer may run low on water causing the **orange** light to blink and the steamer to beep:

- Add water and restart the by turning OFF and ON the *Power* and *Steam* buttons.
- During use, the *Steam Ready* lens will blink indicating the boiler is heating.

SHUT DOWN PROCEDURE / RENTAL RETURN

- 1 Turn OFF *Power* and *Steam* buttons.
- 2 If your steamer has a pressure release valve, open the *Pressure Release Valve* by turning counter-clockwise. *Hot Steam will exit from bottom of steamer.*
- 3 If your steamer does NOT have a release valve, turn off and return to store.



WARNINGS



**STEAM GENERATED BY THIS MACHINE IS EXTREMELY HOT
AND WILL CAUSE INJURY IF IT COMES IN CONTACT
WITH THE SKIN OR EYES.**

- 1) Use only as directed in the user manual. Read full warnings prior to use. Download the user manual at www.rugdoctor.com/support
- 2) Never place any body part in front of nozzle or brush steam. Steam can cause burns.
- 3) Only aim the steam gun at the cleaning area.
- 4) Never unscrew drain plug while steamer is hot.
- 5) Only add tap water to the tank – NO CHEMICALS.
- 6) Do not operate or leave unattended around children.
- 7) Do not use with a damaged cord or plug or if steam cleaners not working as it should.
- 8) Do not operate cleaner or handle electrical plug with wet hands. Do not pull or carry by cord.
- 9) Always turn OFF and unplug when not in use or when moving to another location.

Use only a 12 gauge / 15AMP rated or higher extension cord.





Tile & Grout Cleaner

Operational Guide and Customer Safety

RugDoctor

1-800-784-3628



PROBLEM	SOLUTION
Push Power Button and steamer does not turn ON (No Lights)	Check electrical panel for tripped breaker: <ul style="list-style-type: none"> ➤ The steam cleaner should be the only appliance plugged into an outlet. ➤ Use only a 12 gauge / 15AMP extension cord with maximum length of 25ft.
No response from the trigger button on the hose handle	Check hose connection: <ul style="list-style-type: none"> ➤ Disconnect and reconnect. ➤ You should hear a "click" when connecting hose to the steamer.
Power but no steam <ol style="list-style-type: none"> 1 Check hose connection. 2 Is the Release valve closed? (some steamers do NOT have release valves) 3 Is the pressure dial reading less than 3? 	The steamer is vapor locked and the boiler needs to be drained. <p>Vapor lock: Air is trapped in the water pump:</p> <ol style="list-style-type: none"> 1 Turn OFF and let the steamer cool for at least 10 minutes. 2 Remove drain plug (by hand) located on bottom of the steamer. 3 Drain water and replace drain plug. <p>& Close steam release valve.</p> <ol style="list-style-type: none"> 4 Refill reservoir tank and restart. 
Water is draining from the bottom of the steamer	Close the pressure release valve. NOTE: Not all models have a release valve. <ul style="list-style-type: none"> ➤ Pressure release valve is located next to the fill tank. 

CLEANING: Grout

- 1 Connect the silver extensions and nozzle to hose handle.
 - 2 Attach 1"nylon brush to nozzle.
 - 3 Steam pressure: Medium
- & Apply gentle pressure to the brush during cleaning.
- Let the steam do the work.
 - Steam will push the dirt out of the grout.
- Use a towel to wipe.
- Angle the brush to clean the edges of grout line.

CLEANING: Tile

- 1 Attach large floor brush.
 - 2 Steam pressure: Medium
 - 3 Move slowly over tile allowing steam to penetrate the pores in the tile.
- & It may be necessary to wrap the brush with a towel for deeper cleaning.

Tile & Brush Kit: US100 Includes:

- 1"nylon brush (2 each) and 1"brass brush.
- Brush kits normally clean 200 Sq. Ft.
 - Additional brush kits may be required depending on the size of the cleaning area and the amount of dirt in the grout.

EACH RENTAL INCLUDES



CHECK BEFORE EACH RENTAL

- 1) Listed Supplies are included with the Tile & Grout Cleaner.
- 2) **Don't** forget the brush kits. Each kit should clean approx. 100 sq. ft.
- 3) Water cap is on the Tile & Grout Cleaner.

-The cap does not tighten.

NEED HELP? PLEASE CALL 1-800-784-3628

CAUTION: Read operating instructions carefully before using.



FOR BEST RESULTS

- 1) Operate Tile & Grout Cleaner on MEDIUM steam pressure.
- 2) Most cleaning can be accomplished with the Nylon Brush (A).
-Work the edge of grout lines and then the middle.
- 3) Brass brush (B) is best for heavy soiled areas.
- 4) Floor Brush is utilized to clean tile.
-For a deeper cleaning, wrap a towel around the floor brush and re-steam.